

ORDERING GUIDE: CONVENTIONAL COIL/DISTRIBUTOR TYPE SYSTEMS

IGNITION LEAD ORDER DETAIL

Please complete in **BLOCK CAPITALS**

Your Name: _____

Address: _____

Zip Code: _____

Tel: _____

Fax: _____

Mobile: _____

LEAD TYPE REQUIRED (please tick)

- Copper Core (Black / Unprinted) 7mm *If unsure, please refer to: www.magnecor.com for cable (lead in UK) descriptions and specifications*
- Electrosports 70 (Black) 7mm
- Electrosports 80 (Blue) 8mm
- Competition KV85 (Red) 8.5mm
- R-100 Racing (Red) 10mm

YOUR VEHICLE DETAILS

Vehicle Make/Model: _____ Year: _____


Engine Type: Eg: Honda Civic 1.6

Engine Code: Eg: B16A2

DISTRIBUTOR CAP TYPE

Make: _____ Model: _____

BOOT TYPE AT DISTRIBUTOR CAP: Straight 90° (right angle)



MEASURING YOUR LEADS CORRECTLY

PLEASE READ CAREFULLY TO ENSURE MEASUREMENTS ARE CORRECT.

When measuring existing ignition leads, measure from the spark plug metal terminal end to the distributor or coil metal terminal end (see diagram 1). For leads with deep boots (e.g. 16 valve engines) measure from the centre (see diagram 2). It is best to remove ignition leads from the spark plugs before measuring if the leads are difficult to reach.

Use a dressmaker's tape or alternatively lay a flexible tube/covered wire against the existing ignition lead. These can then be easily measured after the length has been established. This is the most accurate way to arrive at the correct lead lengths.

If no ignition leads are fitted to the engine, establish length by using tubing pipe or covered wire/flex or old ignition leads to make a temporary connection from the distributor to the spark plugs. Using this method will also help ascertain the best possible lead position along the entire length of the proposed ignition lead routing.

When measuring the R-100 10mm leads in particular, remember to take into account that the physical bulk of the 10mm ignition lead might necessitate longer lead lengths in order to go around corners and accessories. Also, fitting R-100 10mm ignition leads into original equipment tubes and brackets may not be possible. However, due to its exceptional flexibility the lead will squeeze into many aftermarket 8mm or larger lead separators.

CAPACITY: _____ NUMBER OF CYLINDERS: _____
 SOHC/DOHC: _____ NUMBER OF VALVES: _____
 TURBO S/CHARGED: CARB INJECTION:

COIL


Make: _____ Model: _____

Coil Lead Length: _____ (cm / inches)

COIL LEAD BOOT TYPES

Coil End: Straight 90° (right angle)
 Distributor End: Straight 90° (right angle)

☑ (please see reference images below and tick or circle your type)



Fax this sheet and any other information to:
(USA) 248-471-9506 or attach it to an e-mail with any photographs etc. to: **sales@magnecor.com**

Diagram 1. (please tick if used





Diagram 2. (please tick if used



OTHER RELEVANT INFORMATION: Eg: Specific Conversion Type

SPARK BOOT PLUG REQUIRED (please see reference images below)

Standard (Black) High Temperature (Red)

SPARK PLUG LEAD LENGTHS (cm / inches)

(Cylinder Numbers)

1) _____ 2) _____ 3) _____ 4) _____
 5) _____ 6) _____ 7) _____ 8) _____
 9) _____ 10) _____ 11) _____ 12) _____

